




ASSEMBLY INSTRUCTION

A2023PL-3 A2123PL-3 A2765PL-5
A8046PL-1 A8018PL-1 A8016PL-1
A5962PL-3 A8086PL-1 A8030PL-1
A8353PL-1 A5930PL-1 A5930PL-2
A5930PL-3 A5930PL-4



ИНСТРУКЦИЯ

A1



3X



1X




1X



3X



A2




1X



1X



A3



1X



2X


1X



2X

3X

3X




1X


2X

3X


B





C




D




E



A1





A2




A3

series item no	ROTATABLE/NONROTATABLE	a	b
A2023PL-3	NONROTATABLE IP44	75	67
A2123PL-3	NONROTATABLE IP44	75	67
A2765PL-5	NONROTATABLE	29	25
A8046PL-1	NONROTATABLE	80	55
A8018PL-1	NONROTATABLE	80	55
A8016PL-1	NONROTATABLE	96	55
A5962PL-3	NONROTATABLE	80	55
A8086PL-1	NONROTATABLE	85	55
A8030PL-1	NONROTATABLE	90	55
A8353PL-1	NONROTATABLE	90	55
A5930PL-1	ROTATABLE	135*135	110*110
A5930PL-2	ROTATABLE	240*135	205*110
A5930PL-3	ROTATABLE	335*135	300*110
A5930PL-4WH	ROTATABLE	250*120	215*110
A5930PL-4SI	ROTATABLE	250*120	215*110
A5930PL-4BK	ROTATABLE	250*120	215*110



E1



F

