












ASSEMBLY INSTRUCTION

A2023PL-3 A2123PL-3 A2765PL-5
 A8046PL-1 A8018PL-1 A8016PL-1
 A5962PL-3 A8086PL-1 A8030PL-1
 A8353PL-1 A5930PL-1 A5930PL-2
 A5930PL-3 A5930PL-4WH A5930PL-4SI A5930PL-4BK



ИНСТРУКЦИЯ



series item no	ROTATABLE/NONROTATABLE	a	b
A2023PL-3	NONROTATABLE IP44	75	67
A2123PL-3	NONROTATABLE IP44	75	67
A2765PL-5	NONROTATABLE	29	25
A8046PL-1	NONROTATABLE	80	55
A8018PL-1	NONROTATABLE	80	55
A8016PL-1	NONROTATABLE	96	55
A5962PL-3	NONROTATABLE	80	55
A8086PL-1	NONROTATABLE	85	55
A8030PL-1	NONROTATABLE	90	55
A8353PL-1	NONROTATABLE	90	55
A5930PL-1	ROTATABLE	135*135	110*110
A5930PL-2	ROTATABLE	240*135	205*110
A5930PL-3	ROTATABLE	335*135	300*110
A5930PL-4WH	ROTATABLE	250*120	215*110
A5930PL-4SI	ROTATABLE	250*120	215*110
A5930PL-4BK	ROTATABLE	250*120	215*110

